

Software Release Notes

Operating System	Windows 7, 8, 10 (64-bit versions)
Firmware version:	1.10.0
Available starting from:	2019-03-01
Released by:	Hella Aglaia GmbH Ullsteinstraße 140 12109 Berlin Germany people.counter.support@hella.com www.people-sensing.com

1 New Features

No.	Description
1	Adaption to new Zone Monitoring features in PS-RS SW versions 1.14 & 1.15

2 Changed Features

No.	Description
1	None

3 Removed Features

No.	Description
1	None

4 Corrected Errors

No.	Description
1	The range overlay (read area) was not displayed correctly on sensors installed with a pitched angle > 0. This error was fixed for PS-RS videos. For PS-M videos another error remains.
2	Converted Videos did not receive the name of the first file in the folder instead of the current filename.
3	An additional line was displayed in the counting line overlay when using digital inputs as an external counting line.
4	In some occasions the framerate of converted videos was incorrect.
5	In some occasions the batch conversion of videos did not convert any videos.
6	Timestamps were not displayed correctly in the overlay.

5 Known issues, restrictions and notes

No.	Description
1	In PS-M videos the range overlay (read area) is not displayed correctly on sensors installed with a pitched angle > 0.

6 Tool Compatibility

The APS people sensor software will be continuously improved, and new features will be added. Thus the video player needs to be extended sometimes as well. However, we strive to keep the program backwards compatible to videos recorded with every older firmware version.

Video Player	APS-M firmware	APS-RS firmware
1.6.0	all versions until 1.2	all versions until 1.8
1.7.0	all versions until 1.4.1	all versions until 1.12
1.8.0	all current versions (at least until 1.5)	all versions until 1.12
1.10.0	all current versions (at least until 1.8)	all current versions (at least until 1.15)

7 Reference documents

Nr.	Title	Date
1	<i>APS-SW-Manual-Videoplayer-1.10.0-en.pdf</i>	03.2019

8 Contact

Questions and support requests can be sent by e-mail to:

people.counter.support@hella.com